

safety platforms ltd

15 Years of improving site safety



PLASTERBOARD TROLLEY USERGUIDE

Call 01924 420820

PLASTERBOARD TROLLEY USERGUIDE

Component list.

- 16 no. Caster bolts
- 16 number split washers
- 8 no. nuts
- 2 no. 2" bolts for bar
- 2 washers
- 2 no. nuts
- 1 no. spigot joining bar
- 2 x bolts and nuts for handrail

1. Remove all components from packaging and confirm that correct items are present.

2. Turn the chassis bottom to face you and place the first castor to be bolted in position.

3. Partially tighten all the bolts and then fully tighten each bolt individually completely. Repeat for other 3 castors.

4. Slot spigot joining bar into handrails and slot bolts through and tighten bolts to form single handrail bar.

5. Turn Plasterboard trolley over and slot the bar into position and insert the 2" screws and fit the washer and bolts.

Please assemble on flat protected surface to maintain the powder coating on chassis.

Carrying capacity – 24 sheets of 12.5mm board (approx)

Carrying capacity 820kg

- Do not exceed maximum carrying capacity
- Do not use on uneven surfaces
- Do not push at excessive speeds
- Take extra care when turning



Safety Platforms Ltd

www.safetyplatforms.co.uk | info@safetyplatforms.co.uk | 01924 420820